

VW Touran 1.8TSI 180HP 2017



1. Box type: VT401200-040.
2. Find two plugs for manifold pressure sensors. Disconnect them and connect box adapters between. It's easy to access to one of them from the bottom of the engine after removing lower engine dust shield.



