

Audi A6 C7 3.0TFSI 310PS

1. Find plugs for manifold pressure sensors. Disconnect them and connect box adapters between.



2. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.