

BMW 650i 4.4 408HP 2011

1. Box type: VT401200-015



2. Find plugs for manifold pressure sensors. Disconnect them and connect box adapters between.



3. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.