

## Skoda Octavia 1.9TDI 90HP

1. Box type: VT101502.
2. Find plug for fuel pump. Disconnect it and connect box adapter between.



3. Connect white wire to pin no.5 of air mass sensor.

