

## Ford Focus 1.6TDCI 90HP 2008

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

