

2013-up VAG 1.6 TDI Engine

1. Box type: VT101202.
2. Find plug for Fuel Rail Pressure Sensors. Disconnect it and connect box adapter between.

