

VAG 2.0TFSI 211PS

1. Box type: VT401200-004.
2. Find plug for manifold pressure sensor. Disconnect it and connect box adapter between.



3. Connect yellow-red wire to positive terminal of a battery.

