


Mitsubishi L200 2.4 DID 154HP 181HP

1. Box type: VT401005.
2. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.



3. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.