


Toyota Auris 1.4 D4D 90HP 2016

1. Box type: VT401201.
2. Remove the engine cover.



3. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.



4. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.