

## Toyota RAV4 2.2D4D 136HP

1. Box type: VT101004
2. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

