

Toyota RAV4 2.2D4D 150HP

1. Box type: VT101002
2. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

