


Fiat Ducato 2.3JTD

1. Box type: VT401201.
2. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.



3. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.